



Love Design. Get Offi!

TRUNDLE DESK

assembly instructions

1. Hardware: 6 - 3 inch screws

2. Tools: Rubber mallet
Philips head screwdriver

3. Start with left or right leg, attach the top and bottom cross rail, align the modez connector on the rails with the modez connector on the leg. Tap gently down with rubber mallet.

Attach the opposite leg, aligning the top and bottom rail, in the same manner. Tap gently

4. Flip main desk over onto its top, align the base of the desk with the underside of the main desk. Screw the base into the main desk in the pre-drilled holes of the base.

5. Once fully attached, flip desk so its stands on its legs. Use levelers to adjust height of desk.



1.



2.



3.



4.



5.